



Hippo Maintenance Manager

Quick Setup Guide 2010
Software Version 3

TABLE OF CONTENTS

PLEASE SELECT TABLE HEADERS TO OPEN CONTENTS IN NEW WINDOW

1 Introduction

2 Basic Setup (On-Demand Work Orders)

2.1.0 Users

- 2.1.1 Add User
- 2.1.2 Edit User
- 2.1.3 Delete User

2.2.0 Locations

- 2.2.1 Add Location
- 2.2.2 Add/Plot Multiple Locations
- 2.2.3 Edit Location
- 2.2.4 Delete Location

2.3.0 Manufacturer Equipment

- 2.3.1 Add Manufacturer Equipment
- 2.3.2 Edit Manufacturer Equipment
- 2.3.3 Delete Manufacturer Equipment

2.4.0 Equipment

- 2.4.1 Add Equipment
- 2.4.2 Edit Equipment
- 2.4.3 Delete Equipment

2.5.0 Companies

- 2.5.1 Add Company
- 2.5.2 Edit Company
- 2.5.3 Delete Company

2.6.0 Contacts

- 2.6.1 Add Contact
- 2.6.2 Edit Contact
- 2.6.3 Delete Contact

2.7.0 Parts

- 2.7.1 Add Part
- 2.7.2 Edit Part
- 2.7.3 Delete Part

2.8.0 Specifications (specs)

- 2.8.1 Add Specification
- 2.8.2 Edit Specification
- 2.8.3 Delete Specification

3 Preventative Maintenance (PM) Work Order SETUP

- 3.1.1 Add PM Work Orders
- 3.1.2 Edit PM Work Order
- 3.1.3 Delete PM Work Orders

4 Vehicle Module

4.1.0 Vehicle

- 4.1.1 Add Vehicle
- 4.1.2 Edit Vehicle
- 4.1.3 Delete Vehicle

4.2.0 Vehicle Fuel

- 4.2.1 Add Vehicle Fuel
- 4.2.2 Edit Vehicle Fuel
- 4.2.3 Delete Vehicle Fuel

4.3.0 Vehicle Insurance

- 4.3.1 Add Vehicle Insurance
- 4.3.2 Edit Vehicle Insurance
- 4.3.3 Delete Vehicle Insurance

4.4.0 Vehicle Preventative Maintenance (PM) Work Order SETUP

- 4.4.1 Add Vehicle PM Work Order
- 4.4.2 Edit Vehicle PM Work Order
- 4.4.3 Delete Vehicle PM Work Order

5 Facility Summary Screen**6 Demand Work Order SETUP**

- 6.1.1 Add Demand Work Order

7 Open/Close Demand Work Order Status**8 Open/Close PM Work Order Status****9 Work Order Search Facility Level**

- 9.1.0 Work Order # Search
- 9.1.1 Work Order Search

10 Calendar

- 10.1.1 Calendar Monthly View
- 10.1.2 Calendar Weekly View
- 10.1.3 Calendar Daily View

11 Reports

- 11.1.1 Add My Reports
- 11.1.2 Creating Current Work Order Reports
- 11.1.3 Creating Maintenance History Reports
- 11.1.4 Creating Inventory Reports

12 Enterprise Version (Admin Functions)**12.1.0 Admin Functions**

- 12.2.0 Facilities
- 12.2.1 Add Facility/Add Enterprise Map
- 12.2.2 Edit Facility
- 12.2.3 Delete Facility
- 12.3.0 Work Order Templates
- 12.3.1 Add WO Templates
- 12.3.2 Edit WO Templates
- 12.3.3 Delete WO Templates
- 12.4.0 Companies
- 12.4.1 Add Company
- 12.4.2 Edit Company
- 12.4.3 Delete Company
- 12.5.0 Users
- 12.5.1 Add User
- 12.5.2 Edit User
- 12.5.3 Delete User
- 12.6.0 Work Order Search Enterprise Level
- 12.7.0 Infectious Control
- 12.7.1 Add Activities
- 12.7.2 Edit Activities
- 12.7.3 Delete Activities
- 12.8.1 Add Risk Group
- 12.8.2 Edit Risk Group
- 12.8.3 Delete Risk Group
- 12.9.1 Add Class
- 12.9.2 Edit Class
- 12.9.3 Delete Class
- 12.10.1 Class Mapping
- 12.11.0 Warehouse Module

- 12.11.1 Add Parts
- 12.11.2 Edit Part
- 12.11.3 Delete Part
- 12.12.1 Add Parts Shipment
- 12.12.2 View Parts Shipment
- 12.13.1 Add Transfer Part
- 12.13.2 View Transfer Part
- 12.14.0 MyHippo
- 12.14.1 View Work Order Categories
- 12.14.2 View Work Order Template
- 12.14.3 Add Work Order Template
- 12.15.0 Reports**
- 12.15.1 Add My Reports
- 12.15.2 Current Work Order Reports
- 12.15.3 Maintenance History Reports
- 12.15.4 Inventory Reports
- 12.16.0 Work Order Extraction
- 12.16.1 Functions & Features Of An Extraction
- 12.16.2 Basic Setup (Current Work Order Report Extraction)

13 Hippo HandHeld Unit

- 13.1.0 New HandHeld Units
- 13.2.0 Keypad Symbol & Viewing Names
- 13.3.0 Starting the Hippo Facility Management Software
- 13.4.0 Main Menu and Login Section
- 13.5.0 Main Section Work Orders
- 13.6.0 Downloading Work Orders
- 13.7.0 Work Order Manager Section
- 13.8.0 Editing Work Order
- 13.9.0 Demand Work Order

14 Building Envelopes

- 14.1.1 Building Envelope Issues
- 14.1.2 Contact an expert

1.0 Introduction

Welcome to the Hippo Maintenance Manager. The Maintenance Manager is designed to help manage your facility maintenance activities, inventory levels and overall maintenance costs. The following document will guide you through the steps necessary to get your Hippo Maintenance Manager installation up and going and enable you to begin tracking your maintenance operations.